How to set up a screen saver on Konica Minolta printers

When a Konica Minolta printer is idle, its panel shows the login screen until the printer goes into low power mode. A Print Director screen saver uses that time to show something else, such as announcements or adverts. It runs until someone touches the panel, which brings back the login screen.

You can create several screen savers and give different printers, or groups of printers, different ones. A screen saver can:

- **Show Images**: a series of pictures, each shown for a set time, repeating;
- **Open External URL**: show a web page from a web address;
- **Custom Web Page**: show a web page made of files you upload to the printer.

Create a screen saver and install it on a printer

1. In Resource Manager, edit the shared device (**Print Management** > **Shared Devices**, double-click the printer) and click **Controller**.
2. On the **General** tab, under **Screen saver**, set **Set screen saver** to **Install screen saver**.
3. Choose the screen saver in **Screen saver**. To create a new one, click **...** beside it, and in the **Search for Konica Minolta Screen Saver** window click **New**.
4. In the **New screen saver** window, enter a **Screen saver name** and choose the **Screen saver type**. Then set it up as described below for that type, and click **OK**.
5. Back in the search window, select the new screen saver and click **OK**.
6. Initialise the printer (**Initialisation** tab, **Initialise now**), then click **OK + Refresh All**.

To give the same screen saver to a group of printers, select them in **Print Management** > **Konica Minolta Integrated**, edit them together, and set **Set screen saver** and **Screen saver** there. Then initialise them.

Show Images

The images are shown in the order in which they appear in the list, and the series repeats.

1. Click **Add image** and choose a JPG, GIF or PNG file. Images are zoomed to fill the panel, which is usually 1024 x 600 or 800 x 480 pixels, so use images of that shape.
2. In the image window that opens, rotate the image if needed and change its **Display name**.
3. In **Show for**, enter how many seconds the image is shown before the next one (10 by default).
4. Click **OK**.
5. Repeat for each image. Use **Move Up** and **Move Down** to change the order, and **Edit image** or **Delete image** to change or remove one.

Together, the images can be at most 10 MB.

Open External URL

Enter the web address in **External URL**, including *http://* or *https://*. The printer must be able to reach that address.

Custom Web Page

1. Click **Add file** for each file of the web page: the page itself and everything it uses, such as images and style sheets. The files must be in the same folder, and their names must not contain spaces.
2. In **Startup file**, choose the page that opens first.

Together, the files can be at most 10 MB.

Change or remove a screen saver

- To change a screen saver, edit it from the **…** button, then initialise the printers that use it again.
- To take it off a printer, set **Set screen saver** to **Remove screen saver** and initialise the printer.
- If you delete a screen saver, the printers that used it are set to **Leave unchanged**, so it stays on them until you remove it.

Related articles

- *Konica Minolta Integrated controller settings*

Print Director version at time of publish: 2.5.15.3. Publish date: 27/10/2026.