


How to change the auto-logout time on Konica Minolta printers

If a user logs in to a Konica Minolta embedded device, there is an inactivity timeout that can be adjusted. After this timeout, the user will be automatically logged out. By default, this is set to 1 minute. To change this timeout, follow these steps:

- Either in the web interface, or at the printer panel, log in to the Administrator settings.
- Navigate to **System Settings > Reset Settings > System auto reset**
- Change the value in the System Auto Reset box and click **OK**.



Document revision date: 2023/10/05
Software version: 2.4.5.3
© 2023 Blue Swift Software CC