Disabling Print Director on Konica Minolta e-Series devices

If you have access to Resource Manager, the best way is to completely remove the embedded applications from the device.

If you do not have access to Resource Manager (perhaps the SQL database is down), then skip the section below to the next section **Disabling Authentication via the Web Interface**.

Removing Print Director applications via Resource Manager

- Open **Resource Manager** (Start > Programs > Print Director 2 > Resource Manager).
- Navigate to **Print Management** > **Shared Devices**.
- Double click the device on the right.
- Click the **Controller** tab.
- Click the **Printing** tab.
- Ensure Enable Secure Document Release checkbox is unticked.
- Click the Initialisation tab.
- Click Gather Info
- After the process is complete, highlight both applications in the list and click **Delete Application**.
- Click OK.
- Click PDAgents.
- Right click the print server on the right and choose **Refresh**.

If you would like to stop PD from tracking the print queues for that device, simply delete the Shared Device from the list.

Disabling Authentication via the Web Interface

If you don't have access to Resource Manager, or perhaps because the **Delete Application** process failed, you can disable authentication via the web Interface of the MFP.

- Open a web browser and enter the IP address of the device in the URL and press enter.
- Log in as Administrator (default password is 1234567812345678).





Web Connection				
SSL is not set-up. Please set up SSL after admin logins to secure safety of the information.				
Login				
User Type	Administrator			
Password				
Data Management Utility				
Starting-up Data Management Utility	Manage Copy Protect Data Go			
	Login			

• Click the User Auth/Account Track menu.

Web Connection 🖞 bizhub C6	150i	Administrator
		∰ Q ☆
НОМЕ	Function Search	
Administrator		Search
6 Maintenance	Case Sensitive	
¥ন্∰ System Settings		
Security		
우 User Auth/Account Track		
뭅 Network		
Е вох		
Printer Settings		
Store Address		





• Under Authentication Type, change the User Authentication drop down to OFF and click OK.

Web Connection 🛒 bizhub C650i		Administrator	
		≦ Q ☆	
< User Auth/Account Track	Authentication Type		
Authentication Type	Authentication Type		
 Account Track Settings 	User Authentication	OFF •	
Print without Authentication	Update Billing Information	Allow	
Simple Authentication setting	Default Authentication Method	ation Method ON (External Server)	
Print Counter List	Public User Access	Restrict	
External Server Settings	Ticket Hold Time Setting (Active	5 Minute (0-	
Logoff Settings	Directory)	600)	
Public User Box Setting		OK Cancel	

• Now log out of the printer.

Disabling Authentication from the printer panel

If you don't have access to Resource Manager or the web interface of the printer, you can disable authentication via the printer panel.

- Press Menu (hard key) then Utility.
- Touch Administrator.
- Enter the password (default is 1234567812345678).
- Touch User Auth/Account Track.
- Touch Authentication Type.
- Touch User Authentication drop down.
- Touch OFF then OK.





			Q ☆ ¥
< User Auth/Account Track	Authentication Type		
Authentication Type	Authentication Type		
 Account Track Settings 	User Authentication	OFF -	
Print without Authentication	Update Billing Information	Allow	
 Simple Authentication setting 	Default Authentication Method	ON (External Server)	
Print Counter List	Public User Access	Restrict	
 External Server Settings 	Ticket Hold Time Setting (Active Directory)	5	Minute (0-600)
Logoff Settings	Account Track		
Public User Box Setting			
User/Account Common Setting		ОК	Cancel
企			



